

G310GS Tractive Shock Level RRP 838

NOTE : BEFORE COMMENCING WORK ON THE CONVERSION, TAKE TIME TO READ THE INSTRUCTIONS CAREFULLY. ALL WORK CAN BE CARRIED OUT BY A COMPETENT MECHANIC, BUT IF YOU ARE UNSURE PLEASE CONTACT US OR A MECHANICAL PROFESSIONAL.

KEEP ALL PARTS THAT ARE REMOVED, AS IT IS POSSIBLE TO REMOVE OUR KITS AND RETURN THE BIKE TO STANDARD, IF REQUIRED

Level 1 Tractive shock fitting	
Tools needed: <ul style="list-style-type: none">• 5mm Allen key• 8mm Allen key• Grease	
1. Support bike with stand under engine so that rear wheel is suspended off the floor.	
2. Remove right side plastic panel.	
3. Remove plastic shock shroud.	
4. Undo and remove lower M10 shock bolt, then remove upper M10 bolt, whilst supporting shock. 5. Remove OEM shock.	
6. Insert new Tractive shock into top mount, make sure the orange adjuster at the top is facing to the left, apply grease to M10 bolt and gently insert and tighten gently, do not fully tighten.	
7. Insert lower M10 bolt and fully tighten, then fully tighten upper bolt.	
8. Replace right plastic cover. 9. Replace plastic shock shroud.	