



Fitting instructions for RRP 520 Husqvarna701/SMC Soft Luggage Racks

NOTE: BEFORE COMMENCING WORK ON THE CONVERSION, TAKE TIME TO READ THE INSTRUCTIONS CAREFULLY. ALL WORK CAN BE CARRIED OUT BY A COMPETENT MECHANIC, BUT IF YOU ARE UNSURE PLEASE CONTACT US OR A MECHANICAL PROFESSIONAL.

KEEP ALL PARTS THAT ARE REMOVED, AS IT IS POSSIBLE TO REMOVE OUR KITS AND RETURN THE BIKE TO STANDARD, IF REQUIRED

1. Remove seat by pulling back front corner of seat, both sides, to unlatch pegs. Pull cord under left side panel to release seat catch, and pull seat off by sliding back and up.

Remove rear pillion footpeg mounts from frame by undoing both M10 screws behind rider footpegs.





2. Remove both M6 screws at front of rear fender spoiler, then undo both torx screws under spoiler. Remove filler cap using key, then pull off spoiler by moving backwards





3. Undo left panel torx screw, then pull panel out from rear and detach snap connector to frame at front, remove panel fully.

Prise open undercut catch on inside rear of right panel (as shown 10) the push tag in on front of panel (hidden behind frame in 12), remove panel fully

On underside of rear fender there are 4 marked points for the position of the holes. Using an 18mm drill, drill out the 4 holes in the positions marked.

Replace fender and tail piece onto bike and secure, then place each of the 4x 22mm long spacers into the holes, so they line up with the M8 threaded inserts in the rear tank moulding.

Lay the new Soft Luggage racks over the spacers, and insert all 4 M8x45 csk screws, with csk washers through racks and into threaded inserts in tank. Do not tighten, leave the screws undone a couple of turns.





NOTE:DO NOT USE LOCTITE, OR SIMILAR, ON THESE SCREWS.

THEY ARE PRONE TO BECOMING STIFF IN THE THREADS IN THE TANK, AND CAN DAMAGE THE INSERTS WHEN BEING UNDONE. IT IS BEST TO GREASE THE THREADS OF THE SCREWS BEFORE ASSEMBLY.

4. Now attach the lower frame mounts to the original rear footrest hanger bolt holes using the M8x30 screws (apply Loctite) and 19mm long spacers. Once all bolts are secure and the luggage frame is positioned correctly, tighten all screws fully.