

WWW.RALLY-RAIDPRODUCTS.CO.UK

**RALLY
RAID**

PRODUCTS.CO.UK

PRODUCTS.CO.UK

RAID

**SOFT LUGGAGE FRAME
FITTING MANUAL**



WWW.RALLY-RAIDPRODUCTS.CO.UK

Soft luggage rack Fitting Instructions

REMOVE THE REAR MUDGUARD FROM TAIL OF BIKE BY REMOVING ALL BOLTS AND FILLER CAP. (2 FROM TOP, 2 FROM SIDE AND 3 UNDERNEATH TAIL.

ENSURE ALL WIRES THAT PASS THROUGH THE TAIL SECTION ARE PLACED CORRECTLY AND WILL NOT FOUL THE THREADED INSERT (AS SHOWN)



IF YOUR REAR MUDGUARD DOES NOT HAVE THE REQUIRED HOLES ALREADY, USING AN 18MM DRILL, LOCATE THE MARKINGS ON THE UNDERSIDE OF THE MUDGUARD AND DRILL THE FOUR HOLES.

(AS SHOWN)

REPLACE MUDGUARD ONTO BIKE AND ENSURE ALL THREADED INSERTS ARE CLEAR BEFORE CONTINUING.



INSERT 4 X 22MM SPACERS INTO THE DRILLED HOLES, SO THEY SIT ON TOP OF THE THREADED INSERTS.



NOTE : DO NOT USE LOCTITE OR SIMILAR ON THESE BOLTS, THEY ARE PRONE TO BECOMING STIFF AND WILL DAMAGE THE THREADED INSERTS.

LAYING THE FRAMES OVER THE SPACERS, USING FOUR M8X60 AND FORM WASHERS LOCATE AND LOOSELY TIGHTEN THE BOLTS.



BE SURE THE SPACERS ARE SITTING CORRECTLY AS SHOWN AND THE FRAMES ARE NOT TOUCHING OR OBSTRUCTING ANY BODYWORK.



NOW ATTACH THE LOWER FRAME MOUNTS TO THE BIKE USING THE M8X30 SCREWS (APPLY LOCTITE) AND 19MM SPACERS PROVIDED, DO NOT OVERTIGHTEN.

ONCE ALL BOLTS ARE SECURE AND THE LUGGAGE FRAME IS CORRECT, TIGHTEN ALL BOLTS FULLY



**FOR FITTING LUGGAGE RACKS WITH REAR RACK
OR REAR TANK**

WHEN USING LUGGAGE FRAME WITH REAR TANK
KIT OR REAR RACK, THE LUGGAGE RACKS MUST BE
PLACED ON TOP OF THE RACK, THEN PLACE
ADDITIONAL 6MM SPACERS (SUPPLIED) BETWEEN
THE RACK AND THE LUGGAGE FRAME

(AS SHOWN)



USING LONGER M8X70 BOLTS AND FORM
WASHERS LOCATE THE THREADED INSERT AND
TIGHTEN ALL FIXINGS LOOSELY, BEFORE FULL
TIGHTENING ALL.

